

ARTICLE

Tubes CH21001 Ozone 10a

Number: 4.26.0207

SPECIFICATIONS

Made in: Germany

HS Code: 38220000

DESCRIPTION

For short-term measurements more than 160 Dräger-Tubes are available to measure the so-called spot concentrations of specific gases. A wide range of different gases and vapours can be detected and measured, e.g.: determining and measuring concentration peaks, measuring personal exposure in the inhalation area, detecting leaks in pipelines, gas installations etc., and air analysis in sewers, shafts and confined spaces.

